

Calculite

Standard Finish & Flange Options

Standard Finish Options

Note: Not all finishes available for all trims.



CL Clear

Clear is the most specular and therefore most efficient finish available. Clear reflectors deliver maximum photometric performance but can produce a mirror image of the interior of the space.



CCL Comfort Clear™

Comfort Clear is a slightly diffuse clear finish, which eliminates iridescence and reduces the mirror image inherent with specular finishes.



CCD Comfort Clear™ Diffuse

Comfort Clear Diffuse is a semi-specular finish that softens the light at the source of the reflector. The finish creates a subtle, even luminance from the reflector cone.



WH White

The matte white finish produces the brightest aperture when illuminated but provides the smoothest transition to most ceilings when off. White is available only with a white flange.



CCZ Champagne Bronze

Champagne Bronze is a semi-specular finish that softens the light at the source of the reflector while providing a warmer reflector appearance. Light output is slightly warmer as well.



GD Gold

Gold is a specular finish that provides a pale tint of color for slightly warming the light output. Reflector appearance mixes well in spaces with gold and brass finishes.



MG

Multigroove trims provide a seamless matte black aluminum baffling that captures stray light for a very low brightness aperture.



BK Black

Black is a specular finish that provides the lowest aperture brightness possible and significantly reduces source identification in a ceiling.

Flange Options



P Polished Flange

5/8" wide integral flange polished and finished to match the appearance of the interior of the reflector (available option on most reflector types).



W White Painted Flange

5/8" wide integral flange painted matte white. Standard trim detail on all reflectors.

Care & Maintenance

If handling of reflectors with Alzak® finish is required, the use of clean white or plastic film gloves is recommended to avoid fingerprints. Alzak® surfaces can be cleaned by the following methods: Wipe off with soft clean, dry lint-free cloth; or wipe off with a soft cloth dampened in mild detergent solution, rinse, then wipe dry with lint-free cloth or paper towel. Avoid gritty cleaning agents.

Note: Not all finishes are available for all trims. Refer to specification sheet for availability.

© 2008 Philips Group